



Izmantošana
For shock valve HK V0590

Produkts

| Apzīmējums | Iestat_anas diapazons min. bar | Iestatīšanas diapazons maks. bar | paredzēts vārstu veidam | H mm | Ø D mm | Svars kg |
|--------------------|-----------------------------------|-------------------------------------|-----------------------------|---------|-----------|-------------|
| HK VML 100 0050 | 5 | 50 | HK V0590 0500 HK V0590 0505 | 40.0 | 10.8 | 0.01 |
| HK VML 102 0100 | 20 | 100 | HK V0590 0500 HK V0590 0505 | 40.0 | 12.0 | 0.01 |
| HK VML 105 0250 | 50 | 250 | HK V0590 0500 HK V0590 0505 | 44.0 | 13.8 | 0.01 |
| HK VML 108 0300 | 80 | 300 | HK V0590 0500 HK V0590 0505 | 42.0 | 14.1 | 0.01 |
| HK VML 005 050 UMS | 5 | 50 | HK V0590 0490 | 35.0 | 10.4 | 0.05 |
| HK VML 020 100 UMS | 20 | 100 | HK V0590 0490 | 31.5 | 12.4 | 0.05 |
| HK VML 050 250 UMS | 50 | 250 | HK V0590 0490 | 31.5 | 12.4 | 0.05 |
| HK VML 080 300 UMS | 80 | 300 | HK V0590 0490 | 37.0 | 13.2 | 0.05 |